


# ■ EXPLODED VIEW

# PROTARGET 3000/4000



## ■ PARTS LIST

NO.	PARTS NO.	PARTS NAME	NO.	PARTS NO.	PARTS NAME	NO.	PARTS NO.	PARTS NAME
1	0232198	DRAG KNOB ASSY.	24	68519	LINK	45	20637	SCREW
2	42081	STOPPER SPRING	25	15687	KICK LEVER(3000)	46	68524	CAM
3	0268514A	CLICK PLATE ASSY.		15692	KICK LEVER (4000)	47	68449	OUTER RING
4	26440	DRAG WASHER	26	20400	SCREW	48	02032112	MAIN BODY ASSY.
5	26437	DRAG WASHER	27	05263	ROTOR(3000)	49	0207391	HANDLE ASSY.
6	26438	DRAG WASHER		05264	ROTOR(4000)	50	412116	PROTECTOR
7	062551DB	SPOOL ASSY.(3000)	28	41536	COVER B(3000)	51	20056D	SCREW
	062552DB	SPOOL ASSY.(4000)			41541	COVER B(4000)	52	152111
8	33327	CLICK CLAW	29	41535	COVER A(3000)	53	23349	SPRING PIN
9	67108	CLICK CLAW SPRING			41540	COVER A(4000)	54	67107
10	21157	CLICK CLAW SCREW	30	0229361	BAIL ARM ASSY.(3000)	55	8425-08-02	ANTI-REVERSE CAM
11	38248	BALL BEARING			0229365	BAIL ARM ASSY.(4000)	56	8405-LD-01
12	42077	STOPPER RING	31	27704	WASHER	57	8406-01-26	ANTI-REVERSE SPRING
13	27453B	CLICK WASHER	32	25096	ROLLER	58	10475	BULL GEAR(3000)
14	13119	CLICK	33	68518	ROLLER HOLDER			10488
15	27694	SPOOL WASHER	34	20633	SCREW	59	342111	OSCILLATOR GUIDE SHAFT
	34031	SHAFT(3000)	35	20637	SCREW	60	11158	OSCILLATOR
16	34046	SHAFT(4000)	36	20610	SCREW	61	20383A	SCREW
	27723	WASHER(3000)	37	30162	BEARING SUPPORT	62	38059	BALL BEARING
17	27686	WASHER(4000)	38	38049	BALL BEARING	63	08282	MAIN GEAR
	20635	SCREW	39	17435	BALL BEARING COLLAR	64	27290A	WASHER
19	18035	HEXAGON NUT	40	68517	HOLDER	65	042112	SIDE PLATE
20	20634	SCREW	41	25089	ROLLER	66	20559	SCREW
21	42021	STOPPER RING	42	17413	INNER RING	67	0219822	HANDLE CAP ASSY.
22	68513	SLIDER	43	09333	PINION GEAR	68	209045	SCREW
23	67145	DEAD POINT SPRING	44	16359	BUSH			