



- |                                    |                                  |                                |
|------------------------------------|----------------------------------|--------------------------------|
| 1 drag knob assembly               | 29 rotor washer                  | 57 body rear cap screw         |
| 2 spool assembly                   | 30 ball bearing fixed screw      | 101 drag knob                  |
| 3 spool click gear fixed plate     | 31 one way clutch fixed washer   | 102 drag knob cover            |
| 4 spool click gear                 | 32 pinion gear ball bearing      | 103 click ball spring          |
| 5 main shaft                       | 33 ball bearing bushing          | 104 click ball                 |
| 6 pinion screw cap                 | 34 one way clutch                | 105 brake spring               |
| 7 pinion cap fixed screw           | 35 one way clutch spring         | 106 impelling seat washer      |
| 8 rotor                            | 36 inner ring                    | 107 impelling seat             |
| 9 line roller screw                | 37 pinion gear                   | 108 impelling seat fixed plate |
| 10 bail arm                        | 38 anti-reverse cam              | 109 fixed plate screw          |
| 11 line roller bushing             | 39 anti-reverse switch           | 201 Retaining Clip             |
| 12 line roller washer              | 40 anti-reverse screw            | 202 key washer                 |
| 13 line roller ball bearing        | 41 anti-reverse spring           | 203 drag washer                |
| 14 line roller                     | 42 body                          | 204 eared washer               |
| 15 line slider                     | 43 handle cap                    | 205 spool                      |
| 16 bail wire                       | 44 Ratchet                       | 206 line clip                  |
| 17 bail holder                     | 45 hexangular washer             | 207 line clip brass needle     |
| 18 bail holder screw               | 46 body ball bearing             | 208 spring brass needle        |
| 19 bail holder side cover          | 47 drive gear                    | 209 spool click spring         |
| 20 bail holder side cover screw(1) | 48 body cover ball bearing       | 210 spool click washer         |
| 21 bail holder side cover screw(2) | 49 oscillating gear ball bearing | 211 click washer brass needle  |
| 22 bail arm screw                  | 50 oscillating gear              |                                |
| 23 kick lever                      | 51 oscillating slider            |                                |
| 24 bail trip shaft                 | 52 oscillating slider screw      |                                |
| 25 trip shaft spring               | 53 body cover                    |                                |
| 26 trip shaft spring seat          | 54 body cover screw              |                                |
| 27 bail arm side cover             | 55 handle                        |                                |
| 28 bail arm side cover screw       | 56 body rear cap                 |                                |