


1000/2000




■ PARTS LIST

NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME
1	DRAG KNOB ASSY.	24	BALL BEARING	48	SCREW
2	STOPPER SPRING	25	WASHER	49	HANDLE ASSY.
3	DRAG WASHER	26	COLLAR	50	SCREW
4	DRAG WASHER	27	BAIL ARM LEVER	51	BULL GEAR
5	SPOOL ASSY.(1000)	28	SCREW	52	OSCILLATOR GUIDE SHAFT
	SPOOL ASSY.(2000)	29	SCREW	53	SCREW
6	LINE CLIP	30	SCREW	54	OSCILLATOR
7	SPRING	31	DEAD POINT SPRING	55	BALL BEARING
8	CLICK WASHER	32	ROTOR	56	MAIN GEAR
9	CLICK SPRING	33	SCREW	57	WASHER
10	CLICK HOLDER	34	BEARING SUPPORT	58	BALL BEARING
11	SPOOL WASHER	35	BALL BEARING	59	SIDE PLATE
12	SHAFT	36	BALL BEARING COLLAR	60	SCREW
13	NUT	37	HOLDER	61	HANDLE CAP ASSY.
14	NUT WASHER	38	ROLLER	62	
15	SCREW	39	INNER RING	63	
16	SCREW	40	PINION GEAR	64	
17	SLIDER	41	BUSH	65	
18	LINK	42	SPRING PIN	66	
19	KICK LEVER	43	CONTROL PLATE	67	
20	COVER A	44	ONE WAY CLUTCH SPRING		
21	BAIL ARM ASSY.	45	OUTER RING		
22	WASHER	46	MAIN BODY ASSY.		
23	ROLLER	47	PROTECTOR		

DESIGNED AND ENGINEERED IN JAPAN

3000/4000



■ PARTS LIST

NO.	PARTS NAME	NO.	PARTS NAME	NO.	PARTS NAME
1	DRAG KNOB ASSY.	24	BALL BEARING	48	SCREW
2	STOPPER SPRING	25	WASHER	49	HANDLE ASSY.
3	DRAG WASHER	26	COLLAR	50	SCREW
4	DRAG WASHER	27	BAIL ARM LEVER	51	BULL GEAR
5	SPOOL ASSY.(1000)	28	SCREW	52	OSCILLATOR GUIDE SHAFT
6	SPOOL ASSY.(2000)	29	SCREW	53	SCREW
7	LINE CLIP	30	SCREW	54	OSCILLATOR
8	SPRING	31	DEAD POINT SPRING	55	BALL BEARING
9	CLICK WASHER	32	ROTOR	56	MAIN GEAR
10	CLICK HOLDER	33	SCREW	57	WASHER
11	SPOOL WASHER	34	BEARING SUPPORT	58	BALL BEARING
12	SHAFT	35	BALL BEARING	59	SIDE PLATE
13	NUT	36	BALL BEARING COLLAR	60	SCREW
14	NUT WASHER	37	HOLDER	61	HANDLE CAP ASSY.
15	SCREW	38	ROLLER	62	"O"RING
16	SCREW	39	INNER RING	63	"O"RING
17	SLIDER	40	PINION GEAR	64	SCREW
18	LINK	41	BUSH	65	KICK CAM
19	KICK LEVER	42	SPRING PIN	66	SCREW
20	COVER A	43	CONTROL PLATE	67	
21	BAIL ARM ASSY.	44	ONE WAY CLUTCH SPRING		
22	WASHER	45	OUTER RING		
23	ROLLER	46	MAIN BODY ASSY.		
		47	PROTECTOR		

DESIGNED AND ENGINEERED IN JAPAN